

CREST	
DS5	DVT/OBDVT
F8.5	DVT/OBDVT
F10	DVT/OBDVT
F12	DVT/OBDVT
F15	DVT/OBDVT
G10	DVLPT/OBDVLPT
H10	DVT/OBDVLPT
H14	DVT/OBDVT
H15	DVLPT/OBDVLPT
S9	DVLPT/OBDVLPT
SP10	DVT/OBDVT
V10	DVLPT, OBDVLPT
Double Pantile	DVT/OBDVT
Double Roman	DVT/OBDVT
Planum	DVLPT/OBDVLPT
Wolds	DVT/OBDVT

FORTICRETE	
Centurion	DVT/OBDVT
Gemini	DVLPT/OBDVLPT
Minislate	DVLPT/OBDVLPT
Senator	DVT/OBDVT
SL8	DVLPT/OBDVLPT
V2	DVT/OBDVT

EDILIANS	
Alpha 10	DVLPT/OBDVLPT
Arboise	DVLPT/OBDVLPT
Beauvoise	DVLPT/OBDVLPT
Double Panne S	DVT/OBDVT
HP10	DVLPT/OBDVLPT
HP17	DVLPT/OBDVLPT
HP20	DVLPT/OBDVLPT
Monopole No.1	DVT/OBDVT
Panne H2	DVT/OBDVT
Panne S	DVT/OBDVT

BREEDON	
Double Roll	DVT/OBDVT
Elite	DVLPT/OBDVLPT
Flat	DVLPT/OBDVLPT
Square Top	DVT/OBDVT

MARLEY	
Anglia Plus	DVT/OBDVT
Ashmore	DVLPT/OBDVLPT
Duo Modern	DVLPT/OBDVLPT
Double Roman	DVT/OBDVT
Edgemere	DVLPT/OBDVLPT
Lincoln	DVT/OBDVT
Ludlow Major	DVT/OBDVT
Ludlow Plus	DVT/OBDVT
Malvern	DVT/OBDVT
Maxima	DVT/OBDVT
Marquess	DVLPT/OBDVLPT
Melbourn	DVLPT/OBDVLPT
Melodie	DVT/OBDVT
Mendip	DVT/OBDVT
Monarch	DVLPT/OBDVLPT
Modern	DVLPT/OBDVLPT
Wessex	DVT/OBDVT

MANNOK (QUINN)	
Devenish	DVLPT/OBDVLPT
Locherne	DVT/OBDVT
Rathmore	DVLPT/OBDVLPT
Western Slate	DVLPT/OBDVLPT

BMI (REDLAND)	
49 Type	DVT/OBDVT
Cambrian	DVS/OBDVT
Cathedral	DVT/OBDVT
Double Roman	DVT/OBDVT
Duo Plain	DVLPT/OBDVLPT
Fenland	DVT/OBDVT
Grovebury	DVT/OBDVT
Landmark Dbl Pantile	DVT/OBDVT
Landmark Slate 10	DVLPT/OBDVLPT
Mini Stonewold	DVLPT/OBDVLPT
Norfolk Pantile	DVT/OBDVT
Old Hollow	DVT/OBDVT
Postel	DVT/OBDVT
Regent	DVT/OBDVT
Renown	DVT/OBDVT
Richmond	DVLPT/OBDVLPT
Richmond 10	DVLPT/OBDVLPT
Saxon 10	DVLPT/OBDVLPT
Stonewold Mkll	DVLPT/OBDVLPT

RUSSELL	
Argyll	DVT/OBDVT
Bute	DVLPT/OBDVLPT
Cheviot	DVT/OBDVT
Derwent	DVT/OBDVT
Double Roman	DVT/OBDVT
Galloway	DVLPT/OBDVLPT
Grampian	DVLPT/OBDVLPT
Highland	DVLPT/OBDVLPT
Lothian	DVLPT/OBDVLPT
Moray	DVLPT/OBDVLPT
Pennine	DVT/OBDVT
Polden	DVLPT/OBDVLPT

WIENERBERGER (SANDTOFT)	
20/20	DVLPT/OBDVLPT
Actua	DVLPT/OBDVLPT
Arcadia	DVT/OBDVT
Balmoral	DVLPT/OBDVLPT
Bridgewater	DVT/OBDVT
Britlock	DVS/OBDVLPT
Calderdale Edge	DVLPT/OBDVLPT
Calderdale Slate	DVLPT/OBDVLPT
Cassius	DVLPT/OBDVLPT
County	DVT/OBDVT
Double Pantile	DVT/OBDVT
Double Roman	DVT/OBDVT
Dual Calderdale	DVLPT/OBDVLPT
Dual TLE	DVLPT/OBDVLPT
Flemish	DVT/OBDVT
Gaelic	DVT/OBDVT
Greenwood	DVT/OBDVT
Lindum	DVT/OBDVT
Modula	DVT/OBDVT
Old English	DVT/OBDVT
Old Hollow	DVT/OBDVT
Olympus	DVT/OBDVT
Neo Pantile	DVT/OBDVT
Rivius	DVLPT/OBDVLPT
Shire Pantile	DVT/OBDVT
Standard Pattern	DVT/OBDVT
Tempest	DVT/OBDVT
TLE	DVLPT/OBDVLPT
Vauban	DVLPT/OBDVLPT

DOUBLE LAP TILES AND SLATES	
Plain Tiles (All)	DVLPT/OBDVLPT SDVT
Slates up to 6mm thick	DVS/OBDVLPT SDVT
Slates 7mm to 15mm thick	DVLPT/OBDVLPT SDVT
Slates 16mm to 22mm thick	DVT/OBDVPT SDVT

### Valley Board Construction Guidelines

In all cases and with all inclined roof valleys, valley troughs and valleys lining materials should be supported by valley boards or sark boards.

Valley boards may be inset or continuous over the rafters. The width of the board should be sufficient to provide a minimum of 50mm end support for the ends of the slate or tile battens.

Where they are inset, they should be a minimum of 12mm thick plywood (or 19mm softwood) and supported on bearers of 50mm x 25mm or similar fixed to the rafter sides and set at a depth to finish the valley board flush with the top of the rafters.

Continuous overlaid valley boards may be used, and should be a minimum of 6mm thick plywood butt jointed only over supporting rafters. On rafter spacings above 400mm, it is recommended that support noggins of 75mm x 50mm minimum are securely fixed under the outer edge of the valley board between the rafters.

The fascia or barge board may be trimmed to allow the valley trough to pass through without flattening the profile. Alternatively a lead or lead replacement socaker may be used if required.

